ARISTON

USER MANUAL

600 // SLIDEOUT HOOD

ARH6SIX

IMPORTANT // Please ensure that you read through this user manual prior to installation and use. This manual contains important information to ensure optimal performance and keep you safe. Please retain your proof of purchase, as this will be required in the event that you require warranty service. Remember to retain this manual for future reference.

www.aristonbrand.com

HELLO

CONGRATULATIONS ON THE SELECTION OF THIS ARISTON APPLIANCE. ARISTON APPLIANCES HAVE BEEN SPECIFICALLY DESIGNED FOR AUSTRALIAN AND NEW ZEALAND KITCHENS.

Please read through this user manual carefully as it contains information that will ensure that your appliance is installed correctly, important operating & care instructions and also some advice of what you need to do if this appliance is not performing as intended.

CONTENTS

HELLO	**2**
CONTENTS	**3**
WARNING & SAFETY INFORMATION	**4**
INSTALLATION & DUCTING	**5**
OPERATING INSTRUCTIONS	**7**
MAINTAINING YOUR RANGEHOOD	**8**
PRODUCT SPECIFICATION	**9**
PROOF OF PURCHASE	**10**
NOTES	**11**
CONTACT DETAILS	**12**

WARNING & SAFETY INFORMATION

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Young children should be supervised to ensure that they do not play with the appliance.
- There shall be adequate ventilation of the room when the rangehood is used at the same time as appliances burning gas or other fuels.
- You must read the details concerning the method and frequency of cleaning.
- There is a fire risk if cleaning is not carried out in accordance with the instructions.
- Do not flambé under the rangehood.
- Exhaust air must not be discharged into an existing flue which is used for exhausting fumes from appliances burning gas or other fuels.
- The minimum distance between the hob surface and the lowest part of the rangehood is 600mm. This distance shall be at least 650mm, if the rangehood is installed over a gas hob. If the instructions for the gas hob specify a greater distance, this has to be taken into account.
- Attention should be given to ensure that any applicable regulations concerning the discharge of exhaust air is fulfilled.
- If the supply cord of this equipment is damaged, it must only be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This appliance has been designed for indoor domestic use only.
- Do not remove or inspect the filters whilst the hood is in operation.

INSTALLATION & DUCTING



10A plug fitted

FIG 1.1

NOTICE // All measurements shown are to be used as a guide only, cutout dimensions should be taken from physical product.



FIG 1.2

IMPORTANT // Before handling the rangehood during installation, it is recommended that you remove the filter to prevent damage.

Fig 1.2 illustrates the minimum height from the hob surface to the underside of the rangehood. Electric hob – 600mm, Gas hob - 650mm.

NOTICE // IF THE INSTRUCTIONS FOR THE GAS HOB SPECIFY A GREATER DISTANCE, THIS HAS TO BE OBSERVED. ANY INSTALLATION ABOVE 750MM WILL COMPROMISE PERFORMANCE.

INSTALLATION & DUCTING





DUCTED OPTION

1. Remove the filter.
2. Optional - replace the 65mm front rail with the 45mm front rail (inc in box)
3. Make sure that internal switch is in ducted position. (see above)
4. Determine the most efficient path for the ductwork, minimise bends and keep the length of the ductwork to a minimum.
5. Before fixing the range hood, drill a hole to accommodate the 120mm ducting that you have selected.
6. It is important to run and finish (install roof / wall caps) prior to installation of the hood.
7. Ensure that access has been allowed for the power cable and plug after installation.
8. Remove the 120mm ducting cover plate and attach the ducting adaptor.
9. Hold the hood up to the underside of the cabinet. Screw the rangehood to the underside of the cabinet. Ensure that you do not damage any of the wiring during installation.
10. Attach the ducting adaptor to the ducting.
11. Re-install filter.
12. Plug in the power to the unit, turn on and test.

RE-CIRCULATING OPTION

1. Remove the filter.
2. Remove the front sealing tape to expose the front vents. Do not remove the top 120mm outlet cover.
3. Make sure that internal switch is in recirculating position. (see above)
4. Drill 4 fixing holes as per the drawing. Ensure that access has been allowed for the power cable and plug.
5. Hold the hood up to the underside of the cabinet; align the 4 holes in the cabinet with the corresponding holes in the hood. Screw the 4 screws from the cabinet side.
6. Re-install filter.
7. Plug in the power to the unit, turn on and test.

Notice // When the rangehood is re-circulating, carbon filters must be installed. This unit is pre-installed with a carbon filter.

WARNING // DO NOT penetrate any screws into the range hood as this may result in electrical hazards.

WARNING // Failure to install the screws or fixing device in accordance with these instructions may result in electrical hazards.



OPERATING INSTRUCTIONS



IMPORTANT // To operate the unit, ensure that the power is turned on and the front visor is fully extended. This will provide access to the light and speed controls.

FAN SPEED

LOW/OFF/HIGH switch - located on the right hand side of the unit.

This unit features 2 speed settings; single line indicate low speed, double lines indicate the high speed.

To turn the unit off, you can either slide the visor into the closed position or set the speed switch to the middle position (off).

LIGHT

On/Off switch - located on the left hand side of the unit as indicated in the diagram above.

MAINTAINING YOUR RANGEHOOD

GENERAL MAINTENANCE

Ensure that the power to the unit is switched off prior to cleaning the unit. Surface should only be cleaned with warm soapy water and a soft non-abrasive cloth. In coastal environments and humid areas more frequent cleaning is required to maintain the finish.

FILTERS

This unit is supplied with a carbon filter designed to eliminate odours from you exhaust fumes. This filter cannot be cleaned and should be replaced every 3–6 months, dependant on use.

Aluminium filters may be ordered from your nearest service centre for ducted installations. Aluminium filters are dishwasher safe or can be cleaned with hot soapy water. Ensure that filters are thoroughly dry before re-installing.

LAMPS

Your range hood is fitted with GU10 halogen lamps. Before replacing, ensure that lamps are completely cool and the power to the unit has been switched off. Replacement lamps can be purchased from your nearest service centre.

To remove the lamp, twist the lamp in an anti-clockwise direction. Be careful when installing the new lamp not to make contact with the skin as this may damage the lamp and shorten its life.

PRODUCT SPECIFICATION

ARISTON

MODEL: **ARH6SIX** SERIAL:

220-240V ~ 50Hz Lights 2 x 40W Max
Total: 200W Motor: 120W

www.aristonbrand.com

Made in PRC

For service please call:
Australia: 1300 815 589
New Zealand: 09 306 1020

5364

PROOF OF PURCHASE

ATTACH YOUR PROOF OF PURCHASE
FOR FUTURE REFERENCE

NOTES

CONTACT DETAILS

AUSTRALIA
ARISIT PTY LIMITED
40-44 Mark Anthony Drive
Dandenong South, VIC 3175
Australia
Ph 1300 815 589
FX (03) 9768 0838
consumer.care@arisit.com

NEW ZEALAND
ARISIT PTY LIMITED
PO Box 68-140
Newton, Auckland
1145
New Zealand
Ph (09) 306 1020
FX (09) 302 0077
sales@aristonappliances.co.nz

ARISTON IS COMMITTED TO ONGOING RESEARCH AND DEVELOPMENT. EVERY EFFORT HAS BEEN MADE TO ENSURE ALL INFORMATION IN THIS USER MANUAL IS CORRECT AT TIME OF GOING TO PRINT.

DIMENSIONS SHOULD BE USED AS A REFERENCE ONLY AND ACTUAL DIMENSIONS SHOULD BE TAKEN FROM THE PHYSICAL PRODUCT ONLY.

MANUFACTURER RESERVES THE RIGHT TO CHANGE SPECIFICATIONS WITHOUT NOTICE

aristonbrand.com

ARISTON

VERSION 1.0